

1196 (A)



CONDOMINIUM VIDEO ENTRY SECURITY SYSTEM

VGX

INSTALLATION MANUAL

Issued; November, 1996
AIPHONE CO., LTD.

CONTENTS



| | PAGE |
|--|---------|
| 1. Mounting Guidelines; | |
| Main Entrance Station..... | 3 ~ 5 |
| Central Control Unit..... | 6 |
| Security Guard Station..... | 7 |
| Video Adaptor..... | 8 |
| 2. Setting; | |
| Residence No. Programming | 8 |
| Main Entrance Station | 9 ~ 11 |
| Door Release Activation Time & | 12 |
| Secret Number | |
| 3. Post-installation check(Operations) | 13 ~ 15 |
| 4. Wiring Diagrams (audio); | |
| Residential Master Station | 16 |
| Trunkage Line Connection | 17 |
| 5. Wiring Diagrams (audio/video); | |
| Residential Master Station | 18 |
| Trunkage Line Connection | 19 |
| Video Distributor Connection | 20 ~ 21 |
| Installing Video Monitor to Security | 22 |
| Guard Station | |
| 6. Specifications | 23 |

Main Entrance Station (VGX-DB ○○ series)

Mounting Guidelines;

1. Weather-resistancy Standards;

The main entrance station models comply with Weather-resistant type in Weather-Proof Testing General Rules for Electrical Machinery Instruments(JIS-C-0920). So, it can be installed outside. But when washing the wall surface by high-pressure hose, be careful that the main entrance station would not be sprayed with watered directly.





2. When there is a space between main entrance station and wall;

Mount the Main Entrance station in either of the three ways, according to the space between the wall and the Main Entrance station(mounting bracket).

(1) When a space is **less than 0 ~ 3mm**, proceed with the standard installation.

(2) When a space is **less than 3 ~ 5mm**, put the weather-stripping(supplied) on back of the mounting bracket.

(3) When a space is **more than 5mm**, apply cauking compound between mounting bracket and wall.



Do NOT apply cauking to bottom side.

Main Entrance Station (VGX-DB ○○ series)

Mounting Guidelines; (cont'd)



3. Main Entrance station installation location;

Install the main entrance station so that the camera center comes to 150cm high from the floor (50cm is an eye-level of the average Japanese adults).

As shown below, the camera can monitor a range of approx. 175cm(UPPER) and approx. 125cm(LOWER)(at the 50cm distance from the camera).

- * Decide the camera mounting height according to the average height of the visitors.


Installation height & monitoring range;




Main Entrance Station (VGX-DB○○ series)

Mounting Guidelines;


- (1) Attach the terminal base to inside of the built-in back box.




- (2) Attach the mounting bracket to built-in back box. (Apply an installation method according to the space between wall and mounting bracket).




- (3) Connect wires and attach connectors.



- (4) Hook the front panel on the projection at the top of the mounting bracket.



- (5) Fasten 2 screws at bottom of front panel.



Accessories Included;


- * Installation Manual(1)
- * Terminal base(1)
- * Terminal base mounting screw(2)
- * Mounting bracket(1)
- * Mounting bracket mounting screw(4)
- * Washer(4)
- * Weather-stripping(3)
- * Cord clamp(1)

To avoid misoperation, be sure to take built-in back box to earth.


Central Control Unit (VGX-3K) Video Control Unit (VGX-MC)

Installation Guidelines;

1. Central Control Unit is designed for use in temperatures ranging from 0°C ~ +40°C.
2. Do not install CCU in places exposed to;
 - * direct sunlight, * on or near heating equipment (stove, air conditioner),
 - * temperature extremes, vapor,
 - * strong static electricity (where carpet is fully laid on the floor),
 - * sand, * vibration, * strong magnetic field
3. It is possible that noise can be induced when installed near radio and TV electromagnetic waves.




Installation;




Mounting bracket & Gang box Mounting Locations;

(1) When a separator is not provided;



(2) When a separator is provided;



When connecting both AC 100~ 120V lines and low voltage lines in the same box, provide a separator to divide.

Electrical Facilities Technical Standard Article 204, Item 3- 1


Provide a rigid separating wall between AC in-house wires and low voltage wires in the gang box earth-grounded at the metallic part, so that both wires would never touch each other.

If the box and a separator is non-metallic(insulator), there is no need to take the box to earth-ground.


Security Guard Station

Installation;


(1) Wall-mounting;




(2) Desk-top installation;



DIMENSIONS;




DIMENSIONS;




* For wiring connections, remove front case in both wall and desk-top mounting.

To remove the front panel;



Remove 2 screws, lift the front case and unplug connectors.

To remove the sub-chassis;



Unscrew at one point on back of the chassis, and turn the chassis upside down and mount onto the gang box. (only for wall-mounting)

Accessories;


- * Operation Manual(1)
- * Hook-knob for wal-mounting(1)
- * Screw for mounting chassis to sub chassis(1)
- * Wood screw for mounting sub chassis to wall(1)

Video Adaptor(VGX-VU)

Installation;

- * The video adaptor must be installed outside the residence for maintenance reason.
- * Select a location where the video adaptor is not exposed to rain, etc.

VGX-VU




Accessories;

- * Screw(2)
- * Wood screw(2)
- * Shorting link(1)

Wiring;

From; Trunkage line
(from control unit, preceeding residence)



To; Next residence

* Only for the last video adaptor(there is no next adaptor), The B1 and B2 terminals remain unconnected, For all other video adaptors make a short between terminals B2 - END with the supplied shorting link.

Residential Number Setting(VG-2G/VG-2A)

* The VGX Condominium Entry Security System needs parallel wiring, and residential station number setting must be made at each residential station. Refer to the supplied RESIDENTIAL STATION NO. & SWITCH SETTING TABLE.

Switch setting;


- (1) The setting switch is located on back of the residential station. When shipped, all the switches are set to lower OFF position(00).
- (2) Set the DIP switch with ball-point pen, etc.

Example;

To set residence number 0513;

| ROOM NO.() | | | | | | | | |
|-------------|-----|---|---|---|-------|---|---|---|
| ON | 1 | 2 | 4 | 8 | 1 | 2 | 4 | 8 |
| | 1+4 | | | | 1+4+8 | | | |
| | 0 | | | | 0 | | | |
| | 05 | | | | 13 | | | |

Fill in room number here.





INITIAL POSITION

First digit of Room number(1 ~ 15)

Second digit of Room number (1 ~ 15)

Residence number setting switch



BACK VIEW RESIDENTIAL STATION

Main Entrance Station (VGX-DB○○ series)

Setting for Entrance Station Capacity

1. Entrance Station Number Setting;

VGX system allows connection of max. 4 main entrance stations.

Setting must be made according to the number of entrance stations and types (with or without cameras).

Upon shipment, each entrance station is so programmed as matched with the system configuration. Please check upon installation. If necessary, change the setting accordingly.


On back of the front panel, the setting mode is clearly marked with ○ on the table.

The following 2 items can be programmed(changed) by the switch setting.

- (1) Security guard station calling by pressing ⊗ button(set to VOID upon shipment).
- (2) Security guard station dial number(100 or 1000).(set to 100 upon shipment).



2. Switch Location

- (1) Remove the front panel.



- (2) Remove the switch cover.

- (3) Replace the cover after switch setting is completed.



Main Entrance Station (VGX-DB ○○ series)

3. Switch setting;


(1) Type of Main Entrance Station;

Proceed with setting switches 102 & 103 following questions below.

At security guard station, entrance station No.(1 ~ 8) and type of audio/video or audio only can be programmed.

Notes; * The number of main entrance stations installed does not correspond with the number of calling main entrance station displayed at security guard station.

* After setting alteration, be sure to press RESET switch.




Main Entrance Station (VGX-DB ○○ series)

3. Switch setting;


(2) Setting for calling Security Guard station with CALL button ☒ ;

1. To make ☒ button dialing void;



When the ON/OFF mode has been changed, be sure to press RESET switch


2. To make ☒ button dialing operational;



(3) Setting for Security Guard station No. 100 or 1000;


Programs the Security Guard station number so as to be dialed with 10-key pad. This dialing is effective also when ☒ button is set to ON.

1. To set a number to 100;




When the ON/OFF mode has been changed, be sure to press RESET switch

2. To set a number to 1000;



(4) Adjustment of open voice speaker volume when acoustic feedback occurs;

When acoustic feedback occurs at Main Entrance station, turn the speaker volume control counterclockwise.



Central Control Unit (VGX-3K)


Door release activation time & Secret Number setting;

Be sure to turn off power, and remove the cover.
Turn on power after all programmings are completed.

Secret Number Setting

Program 4-digit secret numbers.


To set secret number
for 2023;



Door release activation time setting



The activation time can be programmed
in a range from 1 to 60 seconds in
1-second intervals.

To set time for 15 seconds;



SECRET NUMBER 1

TIMER 1



* When door release activation by secret number
is not used;

Set secret number to 0000.

Set activation time to any arbitrary time.

(It is possible to activate door release from Security
Guard station and Residential station).

* When door release function is not used;

Set activation time to 00 (second).

Post-installation check(Operations)

- * All the communications are cut off in approx. 3 minutes.
After all the wirings are completed, proceed with the following system operation checks.

Residential Station;

Receiving a call from Residential Door Station;

4-stroke electronic chime sounds, and visitor call LED(yellow green) flashes(or is lit). While the visitor call LED flashes(is lit), pick up handset and communicate.

Receiving a call from Main Entrance station;

2-stroke electronic chime sounds, and visitor call LED(red) is lit and the image appears on the video monitor. While the visitor call LED flashes(is lit), pick up handset and communicate.

Receiving a call from Security Guard station;

Incoming call is annunciated by Ding-Dong Ding chime.
Simply pick up handset to reply.

Calling Security Guard station;

Pick up handset and press SECURITY CALL button.
Talk after the Security Guard station replies.

Activating electric door release;

While communicating with Main Entrance Station, press DOOR RELEASE button.
Door release activation LED is lit on Main Entrance station, and the door release gets activated during a timer-programmed period of time(door release can only be activated during communication with main entrance station, to avoid mis-operation).

Panic alarm(only in VGX-GVP system);

Firmly depress PANIC ALARM button. The alarm is transmitted.
To stop the signal, remove the cover.

Push the cover from the back to its original position and replace the cover.

| Function | Residential station | Residential door station | | Security Guard station | |
|-------------|---------------------|--------------------------|--------------|----------------------------------|--------------|
| | Alarm signal | Indicator | Alarm signal | Indicator | Alarm signal |
| Panic alarm | Pipo, Pipo | Flashing | Pipo, Pipo | Red LED & room number on display | Wow, wow |

Note;

While communicating with Residential door station, incoming call tone from Security Guard or Main Entrance station sounds softly. Momentarily hang up handset to reply to Security Guard or Main Entrance station's call.

Post-installation check(Operations)(cont'd)

Main Entrance station(VGX-DB series)

Calling the Residential station;

Dial the Room number on 10-key pad, and see the number on digital display. Then, press CALL button. When the residential station replies, the displayed number goes off and communicate handsfree.

If there is no corresponding number, E appears on the digital display. Press CANCEL button and redial.

Activating electric door release;

First press CALL button, and dial the secret number on 10-key pad(there is no number on display). If wrongly dialed, press CANCEL button and redial.

If the secret number is correctly dialed, DOOR RELEASE activation LED is lit and the activation is started. If not correct, E appears on the display.

Calling Security Guard Station on 10-key pad;

Press 100 or 1000 on 10-key pad, the number appears on the display(as programmed). Press CALL button, and the number goes off when the Security Station replies and communicate handsfree.

Calling Security Guard station with ⊗ button; (when programmed for calling with ⊗ button)

Press ⊗ button, and 100 or 1000 appears on the display(as programmed).

Press CALL button, and the number goes off when the Security Guard station replies and communicate handsfree.

Post-installation check(Operations)(cont'd)

Security Guard station

Receiving a call from Residential station;

A call-in from a residence is annunciated by intermittent electronic tone and digital number on the display. See the calling room number, and pick up handset to reply.

Calling each Residential station;

Pick up handset, and dial a Room number (3~4-digit) and see the number on the display. Press CALL button, and communicate when the Residential station replies.

When a busy tone is heard, the Main Entrance station is communicating with the Residential station. Call later.

If the dialed number is not programmed, E appears on the display.

Activating door release;

While communicating with Main Entrance station, press DOOR RELEASE button. The activation indicator LED is lit on Main Entrance station, and the door release gets activated during a timer-programmed period of time (The door release activation is only effective while communicating with Main Entrance station).

Receiving PANIC ALARM signal (in VGX-GVP system only);

When PANIC ALARM signal is transmitted from a Residential station, alarm signal starts and the indicator LED is lit, as well as the Room number is shown on the display.

Press SIGNAL STOP button to mute, but the Room number remains.


After pressing SIGNAL STOP button, you may press ALARM RESET button. The Room number goes off, if the PUNIC button is released at the initialing station.

If the multiple alarm signals have been received at the time, NEXT ALARM indicator LED is lit. Press SIGNAL STOP button, and alarm-originating station numbers are shown consecutively (Max. 20 numbers can be received).


Room number will be shown also by ALARM RESET button, but the number will be released when displayed.

Wiring diagram(audio): Residential Master Station


Wiring



VG-2A-6-E




VG-2G-6-E




Wiring diagram(audio); Trunkage Line Connection


Trunkage Line Connection



Entrance Station Connection




Security Guard Station Connection




Wiring diagram(audio/video): Residential Master Station


Wiring



VG-2A-6-E w/ MY-VU




VG-2G-6-E W/MY-VU




Wiring diagram(audio/video); Trunkage Line Connection

Trunkage Line Connection




Entrance Station Connection




Video distributor connection

Use Video distributor, VD-2Y, when connect more than 30 residence on each trunkage line

Calculate line loss of video distributor, video adaptor and line resistance.
VGX line loss **must not exceed 36.25dB** per trunkage line.




Three VD-2Y's to install 64 VGX-VU's per line (max. 192 stations).




Video distributor connection


Basic wiring block diagram;




Video distribution to max. 40 residences per block;




Video distribution to max. 192 residences in 3 blocks;




Wiring diagram;



Installing Video Monitor to Security Guard Station;



When installing a video monitor to sub security guard station;



Specifications

| | |
|--|--|
| Power source | Central Control unit AC 100 ~ 120V, 50/60Hz. Video Control unit AC 100 ~ 120V, 50/60Hz. Main Entrance station DC 12V, supplied from control unit. Video adaptor DC 12V, - do - Security Guard station DC 12V, - do - |
| Power consumption Current consumption | Central Control unit Max. 28W Video Control unit Max. 65W Main Entrance station Max. 400mA, 100mA(standby) Video adaptor Max. 30mA Security Guard station Max. 800mA, 60mA(standby) |
| Calling | <u>Residential door station to Residential station;</u> 4-stroke electronic chime (w/volume control) and LED flashing or lit for approx. 45 seconds. <u>Main Entrance station to Residential station;</u> 2-stroke electronic chime (w/volume control) and LED flashing or lit for approx. 45 seconds. <u>Security Guard station to Residential station;</u> Chime tone (Ding-dong, ding) <u>Residential station to Security Guard station;</u> Intermittent electronic tone & Room number on display <u>Main entrance station to Security Guard station;</u> 2-stroke electronic chime (w/volume control) |
| Wiring | <u>Central control unit to Main entrance station;</u> 2 twisted pairs, 1.0mm dia. <u>Video control unit to Main entrance station;</u> 2 twisted pairs, 1.0mm dia. <u>Central control unit to Security guard station;</u> 2 twisted pairs, 1.0mm dia. <u>Central control unit to Residential station;</u> 1 twisted pairs, 1.0mm dia. <u>Video control unit/Central control unit to Residential station/Video adaptor;</u> 3 twisted pairs, 1.0mm dia. |
| Wiring distance | <u>Central control unit to Main entrance station;</u> Max. 50m with cable(type CPEV) 2(or 3) twisted pairs, 1.0mm dia. <u>Central control unit to Security guard station;</u> Max. 50m with cable(type CPEV) 2(or 3) twisted pairs, 1.0mm dia. |
| Trunkage line max. extended distance | <u>Audio system;</u> Max. 1000m. <u>Audio/Video system;</u> Max. 1000m, Max. 150m from video control unit to the farthest monitor. |
| Station capacity | 3-wiring block Central Control unit ... Max. 64 Residential stations per block. max. 192 Residential stations in entire system. |

AIPHONE CO., LTD., NAGOYA, JAPAN
AIPHONE CORPORATION, BELLEVUE, WA, USA

