

# This operation guide describes the basic functions of your GT Series Tenant Station

For a complete operation manual (3.15 MB), scan QR code to download it from the manufacturer's website: [www.aiphone.com/gt-1d-op-man](http://www.aiphone.com/gt-1d-op-man)



## T-Mode Hearing Aid Compatible

This tenant station emits an electromagnetic field, producing clear audio for T-Mode compatible hearing aids.

## Power Source


This tenant station is powered by the system and will always remain on. Contact the building manager if the tenant station in this residence is not working.

## Handset

Pick up the handset to answer an incoming call. Hang up the handset to end the conversation.

## Chime Volume Control

Use the switch to adjust the chime volume (off, medium, or high). The Tone Off Indicator Light blinks slowly when the chime is muted.



## Option Button

Push the option button to activate an external device, such as a garage opener (if included).

## Guard Button

Push the guard button to call all guard and/or concierge stations connected to the system (if included).

## Door Release Button

Push the Door Release Button to unlock the entrance during a call.

## Tone Off Indicator Light

## Chime Speaker