

This operation guide describes the basic functions of your GT Series Tenant Station

For complete operation instructions, download the manual from the manufacturer's website: www.aiphone.com

AIPHONE®



GT-1M-L Tenant Station

T-Mode Hearing Aid Compatible

This tenant station emits an electromagnetic field, producing clear audio for T-Mode compatible hearing aids.

Power Source

This tenant station is powered by the system and will always remain on. Contact the building manager if the tenant station in this residence is not working.

Option Button



Push the option button to activate an external device, such as a garage opener (if included).

Guard Button



Push the guard button to call all guard and/or concierge stations connected to the system (if included). While in conversation, push the guard button to view the visitor on a CCTV camera (if enabled).

Door Release Button



Push the Door Release Button to unlock the entrance during a call.

Tone Off Indicator Light

LCD Screen

Handset

Pick up the handset to answer an incoming call. Hang up the handset to end the conversation.

LCD Screen Brightness Control



Use the switch to adjust the LCD screen brightness levels (dark, moderate, or bright).

Chime Volume Control



Use the switch to adjust the chime volume (off, medium, or high). The Tone Off Indicator Light blinks slowly when the chime is muted.

Chime Speaker

