

SYSTEM/MODEL: TD-H/B

MODIFICATION: Installing a call tone volume control

DIFFICULTY LEVEL: 4 - Moderate/hard - Internal connection or component addition.

COMPONENTS REQUIRED: 1. Fixed resistor: 5K to 10K ohm.
2. Variable resistor: 50K ohm

INSTR/OPERATIONS: 1. Cut lead to internal buzzer and install resistors as shown on the diagram.

REFERENCE DRAWING #: 1298-1059,1440-1059

Aiphone's product warranty applies to products properly modified using these instructions.
However, if a unit is damaged as a result of improper modification, the warranty does not apply.

INSTALLING A CALL TONE VOLUME CONTROL

