

SYSTEM/MODEL: TD-H/B

MODIFICATION: Third call tone from DE-UR

DIFFICULTY LEVEL: 3 - Moderate - Removal or replacement of internal components.

COMPONENTS REQUIRED: 1. Resistor: 30K ohm, 1/4 Watt

INSTR/OPERATIONS: 1. Remove and replace resistor R17 with the 30K ohm, 1/4 Watt resistor.
2. Select switch of DE-UR must be set to the "B" position.

REFERENCE DRAWING #: 1298-1056,1123-1056

Aiphone's product warranty applies to products properly modified using these instructions.
However, if a unit is damaged as a result of improper modification, the warranty does not apply.

THIRD CALL TONE (For 3rd door station)

DE-UR Schematic Diagram

