


Video Output Kit

Aiphone Spare Part #261380

Use with MY-2CD, MYH-2CD & MYW-P3L



IMPORTANT!!! Power down all Aiphone equipment before performing any modifications!

INSTALLATION INSTRUCTIONS:

MY-2CD OR MYH-2CD:

- 1. Open monitor from the back by removing four small screws.
- 2. Locate the 2-pin male connection (CN5) near the base of the monitor.
- 3. Plug in 2-pin connector with black and white leads, and run wires out of the back of the unit, along with the Blue and Yellow wires (existing).
- 4. Connect the Black and White wires to the coax cable leading to the remote video monitor or recorder.
- 5. The video signal from this unit is composite, 1V peak to peak. The video signal will only be present when a picture is seen on the monitor that the 2-pin connector is plugged into.

MYW-P3L:

- 1. Open the adaptor from the bottom.
- 2. At the base of the PC board, locate the 2-pin male connection (CN-5) next to SW2 and the Reset Switch.
- 3. Plug in the 2-pin connector. Connect the Black and White wires to the coax cable leading to the video monitor or recorder.
- 4. The video signal from this unit is composite, 1V peak to peak. The video signal will only be present when the is present on the monitor that the 2-pin connector is plugged into.

Aiphone Communication Systems 1700 130th Ave. N.E. Bellevue, WA 98005 (425) 455-0510 FAX (425) 455-0071 TOLL FREE TECHNICAL SUPPORT: (800) 692-0200 TOLL FREE FAX LINE: (800) 832-3765 TECHNICAL SUPPORT E-MAIL: tech-serv@aiphone.com