
# **GH OPTION CONNECTOR**

for Optional Functions

### MOUNTING INSTRUCTIONS

## ■ GH-1KD, GH-1AD, GH-1MD MOUNTING


- 1. Take the mounting bracket off of the master station.
- 2. Plug the 6-pin connector into slot.
- 3. Connect the wires of the 6-pin connector to the auxiliary devices to be used (GH-RY, etc.).
- 4. Attach the mounting bracket to a box. Mount the master station on to the bracket.




### FOR GH-1KD, GH-1AD, GH-1MD

FUNCTION	(WIRE)	
f Doctor call	(Yellow)	
Doctor call	(Orange)	
Relay unit, GH-RY (Blue)	(Blue)	
Relay unit, GH-RY (White)	(White)	
f Optional switch output (*1)	(Gray)	
Optional switch output	(Black)	
(*1) Available on GH-1KD, 1AD on Modification required on the m		
		654321


# WIRING DAIGRAM for GH-1AD, GH-1KD, GH-1MD





### **■ GH-MK MOUNTING**

- 1. Take the mounting bracket and protection shield off of the security guard station.
- 2. Cut out the cable knock-out, as shown by the dotted lines.
- 3. Plug the 6-pin connector into slot.
- 4. Connect the wires of the 6-pin connector to the auxiliary devices to be used (GH-RY, etc.). After wiring, attach the protection shield.
- 5. Attach the mounting bracket to a box. Mount the security guard station on to the bracket.



#### For GH-MK

FUNCTION	(WIRE)		
VIDEO CONTROL OUTPUT - (*2)	(Black)		$\Rightarrow$
\ VIDEO CONTROL OUTPUT +	(Gray)		, ))
Relay unit, GH-RY (White)	(White)		// II
Relay unit, GH-RY (Blue)	(Blue)	_=	
Optional switch output (*1)	(Orange)		
Optional switch output	(Yellow)		
(*1) Modification required on the security	guard station		+
(*2) Modification required on the monitor u	unit.	# # # #	<b>* *</b>
		1 2 2 4	<u> </u>

## WIRING DIAGRAM for GH-MK

