

This operation guide describes the basic functions of your GT Series Tenant Station

For complete operation instructions, download the manual from the manufacturer's website: www.aiphone.com

AIPHONE®




GT-1A Tenant Station

Speaker


Power Source

This tenant station is powered by the system and will always remain on. Contact the building manager if the tenant station in this residence is not working.

Option Button


 Push the option button to activate an external device, such as a garage opener (if included).

Guard Button


 Push the guard button to call all guard and/or concierge stations connected to the system (if included).

Tone Off Indicator Light


Talk/Off Button



Push the Talk/Off button to answer an incoming call. Once answered, conversation becomes hands-free. To "hang up" the conversation, push the Talk/Off button again (this does not turn off the device). If there is a lot of ambient noise at the entrance station, push the Talk/Off button for at least 1 second. Once a "beep" is heard, the conversation mode becomes push-to-talk, which requires the Talk/Off button to be pushed while talking and to be released while listening. The push-to-talk mode helps to reduce sound that can be distracting during hands-free mode. Whether the conversation mode is in hands-free or push-to-talk, the Talk Indicator Light comes on while you speak and will turn off while your visitor speaks.



Door Release Button

 Push the Door Release Button to unlock the entrance during a call.

Microphone

Talk Indicator Light

Chime Volume Control



Use the switch to adjust the chime volume (off, medium, or high). The Tone Off Indicator Light blinks slowly when the chime is muted.

Volume Control



Use the switch to adjust the communication volume (low, medium, or high).