

**SYSTEM/MODEL:** TD-H/B

**MODIFICATION:** Change the call-in time from DE-UR to TD-H/B phones

**DIFFICULTY LEVEL:** 3 - Moderate - Removal or replacement of internal components.

**COMPONENTS REQUIRED:** 1. Capacitors: Less than or greater than 10  $\mu$ fd, 16V.

- INSTR/OPERATIONS:**
1. Remove and replace C13, located on PC-1123 inside the DE-UR.
  2. Adjust the value of the capacitor to achieve the desired length of call-in time from the door station.
  3. For a shorter call-in time, use a 4.7 ~ 6.8  $\mu$ fd capacitor.
  4. For a longer call-in time, use a 15  $\mu$ fd or greater capacitor.

**REFERENCE DRAWING #:** 1298-1061,1123-1061

Aiphone's product warranty applies to products properly modified using these instructions.  
However, if a unit is damaged as a result of improper modification, the warranty does not apply.

# CHANGE THE CALL-IN TIME FROM THE DE-UR

DE-UR Schematic Diagram

